

attention!



teniamo a precisare che, a cause delle innumerevoli applicazioni e condizioni di esercizio, il solo personale di montaggio è responsabile nel verificare se l'applicazione scelta sia adatta per materiale e per peso, importante: il biadesivo tiene su superfici non patinate, non stampate, pulite e prive di grasso!

aufgrund der vielfältigen anwendungsmöglichkeiten und bedingungen, weisen wir ausdrücklich darauf hin, dass die gewählte anwendung jeweils vom monter auf eignung für material und gewicht zu prüfen ist, wichtig: doppelkleber haftet nur auf unbeschichteten, nicht bedruckten, sauberen und fettfreien oberflächen!

due to the numerous possibilities and conditions we strenuously point out that every application must be tested by the fitter to ensure that the product is appropriate for the material to be used and its weight, important: adhesive tape holds only on non coated, non printed surfaces free from grease and dirt!

1 pulire
reinigen
clean

2 asciugare
trocknen
dry

3 applicare
aufbringen
apply

15°C - 25°C

4 aspettare
warten
wait

24h

5 montare
montieren
mount

1

2

adhesive tape

panel

24h
aspettare
warten
wait

1 mm \pm 15g (max. 15kg)

adhesive

panel weight:
1mm adhesive=15g panelweight
p.e. 100mm can hold
panel with 1500g
max panel weight 15kg!

3

remove
fit-up aid

4

click!


5

60mm

6

7

adjustable with
screwdriver

 accessory to make your backframe thief-proof
zubehör: diebstahlsicherung für backframe
accessorio: aggancio a parete a prova di furto

